



Application: Application: Aplicación:

Nissan Armada, Pathfinder, Titan | Infiniti QX56



Location of filter:

On the passenger side of the vehicle behind the glove compartment.

To remove existing filter:

1. With glove compartment closed locate and remove the two screws at the bottom of the glove compartment. (Fig. 1, 2, 3)
2. Open the glove compartment and locate and remove the two upper glove compartment screws on either side. (Fig. 4, 5)
3. Locate and remove the two lower screws on the glove compartment striker plate. (Fig. 6)
4. Gently remove the glove compartment assembly.
5. Locate and remove the screw securing the cabin filter cover and then remove the cover. (Fig. 7, 8)
6. Remove the dirty cabin filters. (Fig 9)
7. Replace the dirty filters by inserting the first clean filter in the housing and sliding to the right.
8. Insert the second filter in the housing and secure the cabin filter cover and screw.
9. To complete installation reverse steps 1-5.

