

Installation Instructions

Cabin Filter

Instrucciones de montaje

Filtro de habitaculo

Notice de montage

Filtre d'habitacle

C16081C

LOCATION: BEHIND THE GLOVE COMPARTMENT*

QUANTITY USED: 2

DEGREE OF DIFFICULTY: MODERATE

ESTIMATED INSTALLATION TIME: 24 MINUTES

Mercedes-Benz

2006-09 ML, R & 2007-09 GL Class

1. Open the glove compartment door.
2. Remove the side panel from the instrument panel using a suitable plastic wedge.
3. Remove the bolts from the glove compartment.
4. Pull glove compartment downward, then disconnect lamp electrical connector.
5. Remove the glove compartment.
6. Remove the cabin air filters cover, Figure 1.
7. Remove the cabin air filters from the housing noting the direction of the arrows for reference during installation.
8. Install the new cabin air filters into the housing.
9. Install the cabin air filters cover.
10. Connect the glove compartment electrical connector.
11. Install the glove compartment, then the bolts.
12. Install the instrument panel side panel.
13. Close the glove compartment door.

