



Application: Application: Aplicación:

Chevrolet Venture | Oldsmobile Silhouette | Pontiac Transport, Transport Montana



Carbon filter replaces particulate.

Location of cabin filters:

Inside of the glove compartment behind the air filter access door on the passenger side of the vehicle.

Tools:

Not required.

To remove existing filters:

1. Open the glove compartment door. (Fig.1)
2. Inside the glove compartment: locate the removable panel on the left hand side of the glove compartment. (Fig. 2)
3. Pull out on the tab on the bottom of the panel to remove the panel as shown in Fig. 2 and Fig. 3.
4. Located behind the panel is the filter access door. (Fig. 4)
5. Pull out on the latch on the left hand side of the filter access door and open the filter access door to the right as shown in Fig. 4.
6. Remove the two filters from the filter compartment as shown in Fig.5.
7. Reverse procedure to install new filters.



1



2



3



4



5