

Installation Instructions

Cabin Filter

Instrucciones de montaje

Filtro de habitaculo

Notice de montage

Filtre d'habitacle


C25532C

LOCATION:	UNDER THE HOOD*
QUANTITY USED:	2
DEGREE OF DIFFICULTY:	MODERATE
ESTIMATED INSTALLATION TIME:	24 MINUTES

BMW 2002-08 7 Series & Alpina

1. Open the hood.
2. Release the cabin air filter duct clamp, Figure 1.
3. Depress the cabin air filter duct lock, then lift the cover upward.
4. Remove the cabin air filter duct from the fresh air duct.
5. Release the cabin air filter retaining clips, then remove the two cabin air filter element from the duct, Figure 2.
6. Install the new cabin air filters into the duct. Engage the filter retaining clips.
7. Install the cabin air filter duct onto the fresh air duct. Secure the duct with the lock and clamp.
8. Close the hood.

⚠ WARNING



Turn The Engine Off
Failure to do so may cause electrocution, burns and severe injury.

