

Installation Instructions

Cabin Filter

Instrucciones de montaje

Filtro de habitaculo

Notice de montage

Filtre d'habitacle


C25542

LOCATION:	UNDER THE HOOD*
QUANTITY USED:	1
DEGREE OF DIFFICULTY:	MODERATE
ESTIMATED INSTALLATION TIME:	24 MINUTES

Saab 1994-98 900 & 1999-2002 9-3

1. Open the hood and disconnect the battery ground cable.
2. Note the position of the windshield wiper blades on the windshield.
3. Remove the windshield wiper arm retaining nuts, then the wiper arms.
4. Remove the cowl panel retaining screws.
5. Disconnect hoses and clamps from the upper cowl panel, then remove the panel.
6. Remove the windshield wiper motor and linkage attaching screws, Figure 1.
7. Disconnect the wiper motor electrical connector, then remove the wiper motor and linkage.
8. Remove the cabin air filter, Figure 2.
9. Install the new cabin air filter element into the housing. Ensure the filter is properly positioned in the housing.
10. Install the wiper motor and linkage.
11. Install the cowl panel and secure with the retaining screws. Ensure the hoses and retainers are properly connected.
12. Install the windshield wiper arms and secure with the retaining nuts.
13. Connect the battery ground cable.

⚠ WARNING



Turn The Engine Off

Failure to do so may cause electrocution, burns and severe injury.

