

Installation Instructions

Cabin Filter

Instrucciones de montaje

Filtro de habitaculo

Notice de montage

Filtre d'habitacle

C25600C

LOCATION: UNDER THE HOOD*

QUANTITY USED: 1

DEGREE OF DIFFICULTY: DIFFICULT

ESTIMATED INSTALLATION TIME: 30 MINUTES

Jaguar 2002-08 X-Type

1. Open the hood.
2. Note position of the windshield wiper blades on the windshield.
3. Remove the windshield wiper arm nut covers.
4. Remove the windshield wiper arm retaining nuts, then remove the wiper arms using a suitable windshield wiper arm puller.
5. Disengage the cowl grille retainers, then remove the cowl grille, Figure 1.
6. Remove the cabin air filter from the cowl grille opening, Figure 2.
7. Install the new cabin air filter element through the cowl grille opening. If filter is equipped with air flow markings, ensure the marking is facing in the proper direction.
8. Install the cowl grille. Ensure all the retainers are properly attached.
9. Position the windshield wiper arms to the pivots, then install the retaining nuts and close the covers.
10. Close the hood.

