



**Application: Application: Aplicación:**

Ford Flex and Taurus; Lincoln MKS and MKT



Fig 1



Fig 2



Fig 3



**Location of cabin filter:**

On the passenger side of the vehicle behind the glove box.

**Tools:**

None required

**To remove existing filter:**

1. To remove the glove box, there are two hinge pins (Fig 1) that must be removed from the bottom of the glove box. Pull the pins towards the center of the glove box to remove them.
2. Open the glove box.
3. There is a dampener cord on the left side of the glove box that must be released. (Fig 2) Pull down on the dampener cord to free it from the glove box, then push from the inside of the glove box to release it.
4. Pull up on the glove box to remove it from its hinges and set it aside. (Fig 3)
5. Unhook the tabs at the bottom of the cabin filter housing cover to remove it. (Fig 4)
6. Remove the old filter from the housing by pulling it straight out. (Fig 5)
7. Insert your new filter into the housing with its airflow indicator arrow pointing down.
8. Reinstall the filter cover by hooking the top tabs into the housing and latching the bottom tabs.
9. Pull the dampener cord out so that you can reconnect it to the glove box.
10. There are three hooks on the bottom edge of the glove box that hook onto three tabs on the bottom of the assembly. Re-hinge the glove box and make sure it is completely secured to the assembly.
11. Close the glove box.
12. Reinstall the two hinge pins on the bottom of the glove box.

Fig 4



Fig 5

