

# C28165

**LOCATION: UNDER HOOD – PASSENGER SIDE**

**QUANTITY USED: 1**

**ESTIMATED INSTALL TIME: 3-7 MINUTES**

## INSTALLATION INSTRUCTIONS:

1. Set the wipers in the position. Open the hood. Dismantle the cover's right hand clips. Remove the clip on the corner tab to the windscreen corner.
2. Loosen the rear main seal halfway. Lift off the foam block and lift up the front edge of the cover so that the hood and clip release on the rear edge. Fold back the corner tab. Fold up the cover halfway.
3. Fold up the clips from the filter holder. Remove the cabin filter. Lift up the drainage hose and clean it. Fit the drainage hose and insert a new cabin air filter. The new filter should be fitted with the arrows directed in towards the car.
4. Fold back the holders clips. Fold down the cover. Fit the corner tab under the windscreen moulding. Insert the hook under the windscreen and press down the cover so that the clips lock. Lift up the foam block and fit the clip. Fit the rear main seal. Check the operation of the wipers. Close the hood.

