

## Installation Instructions

Cabin Filter

### Instrucciones de montaje

Filtro de habitaculo

### Notice de montage

Filtre d'habitacle

## C28233

**LOCATION:** UNDER THE HOOD\*

**QUANTITY USED:** 1

**DEGREE OF DIFFICULTY:** VERY EASY

**ESTIMATED INSTALLATION TIME:** 12 MINUTES

### Volkswagen 1995-2003 EuroVan

1. Open the hood.
2. Unsnap cabin air filter housing retainers and remove the housing and filter, Figure 1.
3. Install the new cabin air filter element and housing. Snap the housing retainers.
4. Close the hood.

