



Application: Application: Aplicación:

Audi 90, A4, S4, Cabriolet, Quattro A4, 90 | Volkswagen Passat



Please use caution when installing and refer to both IB12 and IB12A to determine correct installation instruction for the vehicle.

Location of cabin filter:

In front of the windshield under the cowl trim on the passenger side of the vehicle.

Tools:

Unknown or not required.

To remove existing filter:

1. Remove sealing profile by pulling to the front.
2. Open the three rotary clips on cover.
3. Bend up cover and remove.
4. Unlock retaining clips and remove filter.
5. Reverse the procedure to install new filter.