

C35448 / C35413

LOCATION: UNDER HOOD – PASSENGER SIDE

QUANTITY USED: 1

ESTIMATED INSTALL TIME: 5-10 MINUTES

INSTALLATION INSTRUCTIONS:

1. Open and secure the hood.
2. Locate the filter door near the passenger side of the windshield.
3. Open the filter door and pull out the filter (Push the retaining clip on the filter to release).
4. Install new filter (This filter folds with the longer part on top).
5. Reassemble.
6. Use C35413 if you need the plastic housing.

