

C35477

LOCATION: UNDER HOOD – PASSENGER SIDE

QUANTITY USED: 1

ESTIMATED INSTALL TIME: 3-7 MINUTES

INSTALLATION INSTRUCTIONS:

1. Open and secure hood.
2. Unsnap access cover and you can see the filter.
3. Locate the lever on the left side of the housing, push lever out and remove filter.
4. Install new filter.