

# C35516

**LOCATION: BEHIND GLOVE BOX – PASSENGER SIDE**

**QUANTITY USED: 1**

**ESTIMATED INSTALL TIME: 5-10 MINUTES**

## INSTALLATION INSTRUCTIONS:

1. Open the glove box and push in the sides to release the door guide and swing down the door.
2. Remove the filter housing cover and slide out the old filter.
3. Reinstall and reassemble.

