

C35533

LOCATION:

UNDER HOOD – PASSENGER SIDE

QUANTITY USED:

2

ESTIMATED INSTALL TIME: 5-10 MINUTES

INSTALLATION INSTRUCTIONS:

1. Locate the 2 access grill covers on the underside of the hood.
2. Unscrew the retainers so the access grill folds down.
3. Install new filtes and reassemble.



