

C35551

LOCATION: UNDER DASH – PASSENGER SIDE

QUANTITY USED: 1

ESTIMATED INSTALL TIME: 5-10 MINUTES

INSTALLATION INSTRUCTIONS:

1. Remove the lower panel below the glove box by pulling it downward with both hands.
2. Remove the screw holding the cabin filter bracket.
3. Remove the old filter by pulling straight down.
4. Fit new filter into the housing and replace the cover.