

C35665

LOCATION: UNDER HOOD – DRIVERS SIDE

QUANTITY USED: 1

ESTIMATED INSTALL TIME: 3-7 MINUTES

INSTALLATION INSTRUCTIONS:

1. Open and secure the hood. Disengage the evaporator cover retainers, then remove the cover.
2. Lift the cabin air filter cover off and remove the old filter.
3. Install a new cabin air filter into the housing. Ensure the filter is properly positioned in the housing.
4. Close the cabin filter cover and reinstall the evaporator cover.