

C35668

LOCATION: UNDER HOOD – PASSENGER SIDE

QUANTITY USED: 1

ESTIMATED INSTALL TIME: 5-10 MINUTES

INSTALLATION INSTRUCTIONS:

1. Open and secure hood.
2. Locate the filter housing cover on the passenger side of the cowl.
3. Remove the filter access cover and remove the old filter.
4. Install new filter and reassemble.