

C35763C

LOCATION: UNDER HOOD – PASSENGER SIDE

QUANTITY USED: 1

ESTIMATED INSTALL TIME: 15-20 MINUTES

INSTALLATION INSTRUCTIONS:

1. Remove the wiper arms.
2. Open and secure the hood.
3. Remove the clips on the passenger air vent cowling located just under the window.
4. Lift up cowling and remove and replace the air filter.
5. Reverse process to reinstall.