

C35872

LOCATION: BEHIND THE GLOVE BOX – PASSENGER SIDE

QUANTITY USED: 2

ESTIMATED INSTALL TIME: 15-30 MINUTES

INSTALLATION INSTRUCTIONS:

1. Open the glove box and push in on both sides to disengage.
2. Remove the glove box installation screws.
3. Remove the passenger side console side panel left of the glove box.
4. Disconnect the glove box light harness and remove the glove box.
5. Disconnect the resistor connector on the filter access panel.
6. Remove the old filter and install a new one.
7. Reassemble.