

C35898-CAF1830P

LOCATION: UNDER DASH BEHIND GB – PASSENGER SIDE

QUANTITY USED: 1

ESTIMATED INSTALL TIME: 5-10 MINUTES

INSTALLATION INSTRUCTIONS:

1. Open the glove compartment.
2. Push inward on both sides of the glove compartment to disengage retainers and lower glove compartment.
3. Through the glove compartment opening locate the filter cover and remove.
4. Remove dirty filter and replace with clean filter.
5. Reverse steps 1-3 to complete installation.