

C36076C_{-R22751C}

LOCATION: BEHIND GLOVE BOX – PASSENGER

SIDE QUANTITY USED: 2

ESTIMATED INSTALL TIME: 10-15 MINUTES

INSTALLATION INSTRUCTIONS:

1. Open and Secure hood.
2. Remove plenum cover, release cabin air filter retaining tabs catches and fold the tab back.
3. Remove the cabin air filter and install a new filter.
4. Fold the retaining clip into position and engage catches.
5. Reinstall cover.