

C36091

LOCATION: UNDER HOOD – PASSENGER SIDE

QUANTITY USED: 1

ESTIMATED INSTALL TIME: 5-10 MINUTES

INSTALLATION INSTRUCTIONS:

1. Make sure ignition is turned off.
2. Open and secure the vehicle hood.
3. Peel back the seal strip to the end of the passenger side plenum cover.
4. Remove the plastic clips from the front of the plenum cover, pull upward to release the retaining clips from the vehicle.
5. Remove the cover and then remove the used filter.
6. Insert new filter (You may have to twist to collapse and insert the new filter).
7. Reverse the procedure to complete installation.