

C38908

LOCATION:

UNDER DASH – PASSENGER SIDE

QUANTITY USED:

1

ESTIMATED INSTALL TIME: 10-15 MINUTES

INSTALLATION INSTRUCTIONS:

1. Remove 3 screws from the filter cover located under the glove box.
2. Slide locking tabs to remove filter.
3. Pull filter towards you then down to remove.
4. Replace filter and reassemble.

