

# C45128

**LOCATION: UNDER GLOVE BOX – PASSENGER SIDE QUANTITY**

**USED: 1**

**ESTIMATED INSTALL TIME: 10-15 MINUTES**

## **INSTALLATION INSTRUCTIONS:**

1. Open the glove box and remove the tabs to release the glove box.
2. Detach the damper rod and let the glove box swing down.
3. Remove the filter housing cover.
4. Replace the filter and reassemble.