

C45383 - 2

LOCATION: UNDER HOOD – PASSENGER SIDE

QUANTITY USED: 1

ESTIMATED INSTALL TIME: 5-10 MINUTES

INSTALLATION INSTRUCTIONS:

1. Remove the wiper arms by removing the caps, loosen the screws and lift wiper arms off while rocking them to remove.
2. Open and secure hood.
3. Pull away the cowl insulating strip on the passenger side.
4. Pull cowl cover and remove the filter.
5. Replace filter and reassemble.

