

# CAF1822P

**LOCATION: BEHIND GLOVE BOX – PASSENGER SIDE**

**QUANTITY USED: 1**

**ESTIMATED INSTALL TIME: 5-10 MINUTES**

## **INSTALLATION INSTRUCTIONS:**

1. Open the glove box and remove the screw holding the damper rod and detach.
2. Push in on the sides of the glove box and release the box.
3. Lower the glove box compartment and remove the filter housing.
4. Replace the filter and reassemble.

