

R22174

LOCATION: BEHIND GLOVE BOX – PASSENGER SIDE

QUANTITY USED: 1

ESTIMATED INSTALL TIME: 10-15 MINUTES

INSTALLATION INSTRUCTIONS:

1. Refer to the owners manual for instruction.

PLEASE NOTIFY US via EMAIL IF YOU COME ACROSS THE INSTRUCTIONS FOR THIS VEHICLE. mattc@filpac.net