

R22383

LOCATION: UNDER HOOD – PASSENGER SIDE

QUANTITY USED: 1

ESTIMATED INSTALL TIME: 5-10 MINUTES

INSTALLATION INSTRUCTIONS:

1. Open and secure the hood. Use a socket wrench and a screwdriver to remove the cover plate on top of the firewall between the motor and front windshield.
2. Locate the black case that is just below the firewall cover plate on the front passenger side of the vehicle. The case is about 3 by 12 inches across the top and about 8" deep. Open the case using a screwdriver to slide under the cover and pop the tabs that hold the lid on the case.
3. Remove the old filters and vacuum out the housing.
4. Place the new filter inside the case and close the lid, snapping the tabs back into place. Replace the cover plate over the top of the firewall and secure with the screws.